11/28/2017 Simulation Viewer

Lab Report

Your Performance

Your Score: 0 of 2 (0%) Pass Status: Not Pass Elapsed Time: 1 minute 30 seconds Required Score: 100%

Task Summary

X Plug the workstation into the network

✗ Configure TCP/IP settings **Show Details**

Explanation

You will need to fix the following problems:

- Connect the computer to the network.
- Modify the TCP/IP settings for the computer to match the network configuration:
 - For the workstation IP address, choose any address between 192.168.0.15 and 192.168.0.254 except for the addresses of the workstations (192.168.0.30 - 192.168.0.34).
 - Use 255.255.255.0 for the subnet mask.
 - For the default gateway, use 192.168.0.5.
 - For the DNS server, use either 163.128.80.93 or 163.128.78.93 (default values).

Complete the following steps:

- 1. In Windows, begin by verifying the problem. Notice the X over the network connection in the System Tray.
- 2. Right click the network icon in the System Tray and select **Open Network and Sharing Center**.
- 3. The network map shows no connection to the Internet. To help determine why, click the Change adapter settings link.
- 4. Notice the status for the network connection (cable unplugged). To correct the problem, click the Office 1 link at the top to work with the computer hardware.
- 5. In the Workspace area, switch to the back view of the computer.
- 6. The computer has a network cable, but the link light is not on. To see what is connected to the other end, click on the network cable connected to the computer.
- 7. In the Selected Component window, notice that one end is unconnected. Select the unconnected end and drag it to the network connection on the wall plate.
- 8. Switch to the operating system view.
- 9. The System Tray shows a network connection, but the network map in the Network and Sharing Center does not show an Internet connection. To verify the connection configuration, click the Ethernet link.
- 10. Click Details.
- 11. Compare the current TCP/IP configuration with the required configuration to identify the values that are not correct for the network. Click Close.
- 12. To modify the TCP/IP configuration, click **Properties**.
- 13. Select Internet Protocol Version 4 (TCP/IPv4), then click Properties.
- 14. Configure the necessary values to connect to the network. Click **OK**.
- 15. Click Close.
- 16. Verify the Internet connection in the Network and Sharing Center.